

Vancouver Energy
Operations Facility Oil Handling Manual
EFSEC Application for Site Certification No. 2013-01
Docket No. EF131590



Appendix E
Response Equipment Instructions



Appendix E

Response Equipment Instructions

Instructions for Use of Response Boat

- Use boathouse key to unlock boathouse.
- Put on life jackets. Ensure all proper PPE is in good service and in use.
- Open garage door.
- Remove boat well stabilizers, from beneath response boat.
- Lower boat via electric winches.
- Check fuel level.
- Turn on batteries.
- Start engine.
- Back boat out of boathouse.
- Operate boat in accordance with safe boating practice.

Instructions for Use of Boom

- Attach bridal leader to boat cleat.
- Deploy boom slowly, in a straight line.
- When boom is fully deployed, response boat is to turn north and deploy boom according to the Facility's Contingency Plan.

Instructions for Use of Anchors

- Secure anchor line to boom.
- Stretch line until taut and deploy anchor.

Instructions for Use of Sorbents

- Place sorbents within boomed area to absorb oil.

Instructions for Use of Fire Extinguishers

- Position yourself 8 to 10 feet from the blaze.
- Hold unit upright, pull pin.
- Squeeze lever, aim at base of flame, and sweep the foam spray from side to side.
- Advance toward flames over area that has been extinguished, while maintaining 8- to 10-foot distance.

Instructions for Use of Radios

- Turn on.
- Key microphone to talk.
- Refer to Northwest Area Contingency Plan, Tab labeled "Radio Frequencies" for proper frequencies to utilize when using the Motorola MT 2000 radios.
- When using Motorola CT 250, Channel 2 is to be used to communicate between oil companies. Channel 1 is for Facility use only.

Vancouver Energy Operations Facility Oil Handling Manual			
Document No.	Original Issue Date	Revision Date	Issuing Authority
OP.05	2015-06-26		K. Flint
Page E-1 of E-1			

